



DRIVE IN STYLE



NO-NONSENSE OVERDRIVE

Overdrive pedal designed to capture the classic rock crunch with any kind of amp. Make you clean amp roar or beat the beast out from your driven amp

DRIVE

Controls the amount of distortion from very light breakup to serious 80's hard rock crunch. Adjust to taste

STYLE

Midrange control to match your style with the amp you are using. Adjust clockwise to enhance mid frequencies, counter clockwise to scoop the mids

LEVEL

Output volume control. There's plenty of output to boost your amp even with the low DRIVE settings

MYSTIQUE KNOB WITH NO LABEL

Controls the low frequencies of your guitar signal before the drive circuit. With higher DRIVE settings or when boosting a driven amp set fully clockwise to get more clarity and attack. When using DiS with the clean amp set fully counter clockwise to get more warmth and fullness to your sound. Adjust with your right hand.

Power supply 9VDC center negative. No battery operation

Current draw 1,135 mA

True bypass Yes

No nonsense 100%

Contact orders@skippersamps.com

- Handbuilt in Hellsinki, Finland -